

OWNERS MANUALS – PIM

PILOT OPERATING HANDBOOKS (POH)

Part No.	Description	Price
14-02654	POH Cessna 185A-D 1961-1965	---
17-00141	POH Beech Duchess 76	---
14-03355	POH Cessna 152 1979	---
14-03359	POH Cessna 152 1980	---
14-03364	POH Cessna 152 1981	---
14-03370	POH Cessna 152 1982	---
14-03386	POH Cessna 152 1985	---
14-03431	POH Cessna 172RG 1985	---
14-03375	POH Cessna 172P 1983	---
14-03387	POH Cessna 172P 1985	---
14-03388	POH Cessna 172P 1986	---
14-03380	POH Cessna 172Q 1983	---
14-03381	POH Cessna 172P 1984	---
14-03382	POH Cessna 172Q 1984	---
14-03352	POH Cessna 172R NAVIII GFC700 Pilots Information Manual	---
14-03351	POH Cessna 172R (180HP)	---
14-03365	POH Cessna 172P 1981	---
17-00149	POH C172Nn 1978 Floatplane	---
14-02638	POH Cessna 172K (Army 7-41A)	---
14-02658	POH Cessna 180 1953	---
14-02659	POH Cessna 180 1954	---
14-02660	POH Cessna 180 1955	---
14-02661	POH Cessna 180 1956	---
14-02662	POH Cessna 180 1957	---
14-02663	POH Cessna 180 1958	---
14-02664	POH Cessna 180 1959	---
14-02665	POH Cessna 180 1960	---
14-02666	POH Cessna 180 1961	---
14-02667	POH Cessna 180 1962	---
14-02668	POH Cessna 180 1963	---
14-02669	POH Cessna 180 1964	---
14-02670	POH Cessna 180 1965	---
14-02671	POH Cessna 180 1966	---
14-02672	POH Cessna 180 1967	---
14-02673	POH Cessna 180 1968	---
14-02674	POH Cessna 180 1968	---
14-02675	POH Cessna 180 1970	---
14-02676	POH Cessna 180 1971-1972	---
14-02677	POH Cessna 180 1973	---
14-02678	POH Cessna 180 1974	---
14-02679	POH Cessna 180 1975	---
14-02680	POH Cessna 180 1963-1968 Supplement	---
14-02681	POH Cessna 180 1969-1972 Supplement	---
14-02682	POH Cessna 180J 1975 Supplement	---
14-03353	POH Cessna 182S Nav II	---
14-03383	POH Cessna 182R 1984	---
14-02640	POH Cessna 185 1961	---
14-02641	POH Cessna 185 1963	---
14-02642	POH Cessna 185 1964	---
14-02643	POH Cessna 185 1965	---
14-02644	POH Cessna 185 1966	---
14-02645	POH Cessna 185 1967	---
14-02646	POH Cessna 185 1968	---
14-02647	POH Cessna 185 1969	---
14-02648	POH Cessna 185 1970	---
14-02652	POH Cessna 185 1974	---
14-02655	POH Cessna 185 1966 Supplement	---
14-02656	POH Cessna 185 1967-1968 Supplement	---
14-02657	POH Cessna 185 1967-1972 Supplement	---
14-02635	POH Cessna 185A 1965	---
14-02649	POH Cessna A185E 1970-1972	---
14-02651	POH Cessna A185F 1973	---
14-02650	POH Cessna A185F 1973-1974	---
14-03360	Cessna A188B 1980 Flight Manual	---
14-03366	Cessna A188B 1981 Flight Manual	---
14-03371	Cessna A188B 1982 Flight Manual	---
14-03376	Cessna A188B 1983 Flight Manual	---
14-03361	Cessna T188C 1980 Flight Manual	---
14-03367	Cessna T188C 1981 Flight Manual	---
14-03372	Cessna T188C 1982 Flight Manual	---

Part No.	Description	Price
14-03377	Cessna T188C 1983 Flight Manual	---
14-03356	POH Cessna 207A 1979	---
14-03362	POH Cessna 207A 1980	---
14-03368	POH Cessna 207A 1981	---
14-03373	POH Cessna 207A 1982	---
14-03378	POH Cessna 207A 1983	---
14-03384	POH Cessna 207A 1984	---
14-03357	POH Cessna T207A 1979	---
14-03363	POH Cessna T207A 1980	---
14-03369	POH Cessna T207A 1981	---
14-03374	POH Cessna T207A 1982	---
14-01349	Cessna T207A 1983 Pilots Information Manual	---
14-03385	POH Cessna T207A 1984	---
14-03389	POH Cessna 208B (600 SHP)	---
14-03391	POH Cessna 208 (675 HP)	---
14-03390	POH Cessna 208B (675 SHP)	---
14-03354	POH Cessna 208B (867 SHP)	---
14-03389	POH Cessna 208B (600 SHP)	---
14-03391	POH Cessna 208 (675 HP)	---
14-03390	POH Cessna 208B (675 SHP)	---
14-03354	POH Cessna 208B (867 SHP)	---
14-03392	POH Cessna 310R 1979	---
14-03402	POH Cessna 310R 1980	---
14-03412	POH Cessna 310R 1981	---
14-03393	POH Cessna T310R 1979	---
14-03403	POH Cessna T310R 1980	---
14-03413	POH Cessna T310R 1981	---
14-03394	POH Cessna 337H 1979	---
14-03404	POH Cessna 337H 1980	---
14-03396	POH Cessna P337H 1979	---
14-03406	POH Cessna P337H 1980	---
14-03395	POH Cessna T337H 1979	---
14-03405	POH Cessna T337H 1980	---
14-03397	POH Cessna 340A 1979	---
14-03407	POH Cessna 340A 1980	---
14-03414	POH Cessna 340A 1981	---
14-03419	POH Cessna 340A 1982	---
14-03423	POH Cessna 340A 1984	---
14-03398	POH Cessna 402C 1979	---
14-03408	POH Cessna 402C 1980	---
14-03415	POH Cessna 402C 1981	---
14-03420	POH Cessna 402C 1982	---
14-03424	POH Cessna 402C 1984	---
14-03427	POH Cessna 402C 1985	---
14-03399	POH Cessna 404 1979	---
14-03409	POH Cessna 404 1980	---
14-03416	POH Cessna 404 1981	---
14-03400	POH Cessna 414A 1979	---
14-03410	POH Cessna 414A 1980	---
14-03417	POH Cessna 414A 1981	---
14-03421	POH Cessna 414A 1982	---
14-03425	POH Cessna 414A 1984	---
14-03428	POH Cessna 414A 1985	---
14-03401	POH Cessna 421C 1979	---
14-03411	POH Cessna 421C 1980	---
14-03418	POH Cessna 421C 1981	---
14-03422	POH Cessna 421C 1982	---
14-03426	POH Cessna 421C 1984	---
14-03429	POH Cessna 421C 1985	---
14-02639	POH Cessna FR172J Reims Rocket	---
14-02637	POH Cessna R172E (Army 7-41B)	---
14-02636	POH Cessna Skylark 1962	---
14-02634	POH Grumman Amcan AA-5 & Traveler	---
13-18023	PSTR B757 Cockpit	---
17-00173	Grumman Cheetah AA-5A 1977-1979	---
17-00174	Learjet 35A/36A Century III	---
17-00175	Mooney M20j 1980 Pilot Operating Manual	---
17-00134	Piper PA-23-250 Aztec E (1960-1961)	---
17-00135	Piper PA-23-250 Aztec E 1970-75 Pilots Information Manual (Part# 761-455)	---