

CLEVELAND WHEEL & BRAKE PARTS

CLEVELAND GREASE SEALS

Description	Part No.	Price
153-04200 Grease Seal Ring	05-11612	---
154-00800 Grease Seal Felt	05-11613	---
154-01200 Grease Seal Felt	05-11615	---
154-02600 Grease Seal Felt	05-11616	---
154-02800 Grease Seal Felt	05-11617	---
154-03200 Grease Seal	05-11618	---
154-03500 Grease Seal	05-11619	---
154-03600 Grease Seal	05-11620	---
154-07500 Grease Seal	05-11621	---
154-30010 Grease Seal Felt	05-11622	---
154-00400 Clev Felt Seal	154-00400	---
154-01400 Clev Felt Seal	154-01400	---
154-00500 Clev Felt Seal	06-01193	---
153-00500 Clev Grease Ring	153-00500	---
153-00900 Clev Grease Ring	06-01192	---
154-13100 Grease Seal, Molded	05-12775	---
Molded Grease Seal 40-77, 40-77A, 40-77B	06-02819	---
199-507 Seal Repair Kit	05-14563	---
199-53500 Seal Repair Kit	05-14571	---
199-53801 Seal Repair	05-14572	---

CLEVELAND BEARING CONE/CUPS

Description	Part No.	Price
214-00200 Bearing Cone	05-14605	---
214-00300 Bearing Cup	05-14606	---
214-00400 Bearing Cone	05-14607	---
214-00600 BRG Cone/Timken L21549	05-14608	---
214-00700 Bearing Cup	05-14609	---
214-00800 Bearing Cone	05-14610	---
214-00900 Bearing Cup	05-14611	---
214-01000 Bearing Cone	05-14612	---
214-03300 Bearing Cone	05-11639	---
214-03400 Bearing Cup	05-14625	---
214-13200 Bearing Cone	05-14642	---
214-00100 Cup Bearing	06-03305	---
214-01100 BRG Cup, Corrosion Resistant	05-14613	---
214-01200 BRG Cone, Corrosion Resistant	05-14614	---
214-01400 Bearing Cone	05-14615	---
214-01700 BRG Cup/Timken 19268 CP	05-14617	---
214-02000 BRG Cone/Timken 07100 CP	05-14620	---
214-02800 Cone, Bearing	05-14621	---
214-02900 Cup, Bearing	05-14622	---
214-03000 Bearing Cup	05-14623	---
214-03100 Bearing Cone	05-14624	---
214-03400 BRG Cup/Timken 07204	05-14625	---
214-03800 Bearing/ Timken 13600LA-902A3	05-14626	---
214-04300 Bearing Cone	05-14627	---
214-04400 Bearing/Timken LM29700LA-902A1	05-14628	---
214-04500 BRG Cone/Timken LM503349	05-14629	---
214-04600 BRG Cup/Timken LM503310	05-14630	---
214-04700 BRG Cone/Timken 18690	05-14631	---
214-04800 BRG Cup/Timken 18620	05-14632	---
214-04900 BRG Cone/Timken 18685	05-14633	---
214-05100 BRG Cup/ Timken 08231 CP	05-14634	---
214-06300 BRG Cup/Timken 13830	05-14635	---
214-09200 Bearing Cone	05-14636	---
214-12300 Cone, Bearing	05-14637	---
214-12400 Cup, Bearing	05-14638	---
214-12900 Cup, Bearing	05-14639	---
214-13000 Cone, Bearing	05-14640	---
214-13100 Cup, Bearing	05-14641	---
214-13200 Cone, Bearing	05-14642	---
214-18200 BRG Cone - Chrome Plated	05-14643	---
214-18337 BRG Cup - Chrome Plated	05-14644	---
214-30371 Bearing	05-14645	---
214-39250 BRG Cone - Chrome Plated	05-14646	---
214-39412 BRG Cup/Timken 39412	05-14647	---
214-39422 BRG Cup - Chrome Plated	05-14648	---
214-80900 Spherical Bearing	05-14649	---
214-83500 Bearing, Spherical	05-14650	---

CLEVELAND STATORS

Description	Part No.	Price
232-00300 Cleveland Stator	06-02564	---

CLEVELAND HOSE ASSEMBLIES

Description	Part No.	Price
207-00600 Hose Assembly	05-14589	---
207-01600 Hose Assembly	05-14595	---

CLEVELAND SNAP RINGS

Description	Part No.	Price
155-00600 Cleveland Snap Ring 155-6	05-11623	---
155-02900 Snap Ring	05-11624	---
155-04400 Snap Ring	05-11625	---
155-04800 Cleveland Snap Ring T5304-15	06-02562	---
155-14300 Snap Ring	05-14375	---

CLEVELAND WEAR PADS

Description	Part No.	Price
109-00100 Wear Pad	05-11607	---
109-00200 Wear Pad	05-11608	---
109-02800 Cleveland Wear Pad	06-02561	---
109-03000 Cleveland Wear Pad	109-03000	---
109-01500 Wear Pad	06-02795	---
109-00100 Wear Pad	05-11607	---
109-00201 Wear Pad	05-14214	---

CLEVELAND WHEEL AND BRAKE PARTS

Description	Part No.	Price
065- . Torque Plate Assembly	05-11570	---
30-182. Brake Assembly	06-02566	---
30-54C Brake Assembly	05-11654	---
091-11900 Brake Cylinder Assembly	06-02820	---
162-00600 Outer Wheel Half	06-00015	---
162-02100 Outer Wheel Half	06-02100	---
161-044700 Inner Wheel Half	05-14419	---
162-04500 Outer Wheel Half	05-14476	---
162-04700 Outer Wheel Half	06-00114	---
075-17100 Torque Plate Assembly	05-13855	---
075-20301 Tube, Torque, Assembly	05-13860	---
103-11700 Anchor Bolt	06-00078	---
069-00200 Anchor Bolt	069-00200	---
177-00300 Pin	07-00003	---
068-01100 Insulating Shim	06-01197	---
199-516 O-Ring Kit	08-00353	---
214-01300 Bearing Cup	05-11637	---
095-01100 Washer	095-01100	---
111-08200 Adjuster Assembly	05-11610	---
107-03700 Wiper	107-03700	---
107-00500 Wiper Ring	05-11606	---
107-03100 Wiper Ring	05-14213	---
MS35266-61 Screw for 102-07100	06-02560	---
095-02600 Seal for Master Cylinder	05-11587	---
110-15300 Bumper Heat Shield	05-14218	---
095-03000 Washer	05-11588	---
094-10401 MS21045-5S Nut	06-02558	---
158-01300 Hubcap	05-11626	---
158-00300 Hubcap	158-00300	---
159-02700 Hubcap	05-11626	---
177-00400 Pin	06-01194	---
177-01600 Pin	05-11632	---
160-01100 Valve Stem	05-14404	---
160-01200 Valve Assembly	05-14405	---
106-01900 Inflation Valve	05-11629	---
082-02000 Spring	05-13887	---
102-33300 Screw	05-14119	---
102-00600 Screw 8-32X.250 Zinc	05-14113	---
094-91500 Nut MS21045-6S	05-14006	---
094-13800 Nut	05-13996	---
094-13200 Nut 42FLW-524	05-13995	---
1J2-2 Airborne Filter	05-11636	---
700-8 Dustshield Size	157-01000	---
106-02000 Inflation Valve Assembly	160-02000	---
199-52 Repair Kit	06-00834	---
ID Plate	166-21600	---
082-02000 Clev Spring	05-13887	---
082-05300 Clev Spring	05-13890	---

CLEVELAND DRIVE KEY

Description	Part No.	Price	Description	Part No.	Price
205-00700 Drive Key	05-14581	---	205-05201 Drive Key	05-14587	---
205-04400 Drive Key	05-14585	---	205-00600 Key Liner	05-14580	---
205-05000 Drive Key	05-14586	---			

CLEVELAND O-RINGS

Description	Part No.	Price	Description	Part No.	Price
101-50353	05-06395	---	101-61800	05-11596	---
101-27900	05-11591	---	101-60001	05-11593	---
101-28000	05-11592	---	101-24900	05-14076	---
101-60001	05-11593	---	101-24600	05-14075	---
101-60100	05-11594	---	101-24200	05-14073	---

SEE WEBSITE FOR COMPLETE LISTING OF COMPLETE PARTS