

# WHELEN STROBES

## STROBE SYSTEM PARTS

| Model No.      | Description  | Part No. | Price |
|----------------|--|----------|-------|
| A402R          | Red Optic Lens   | 11-03254 | ---   |
| A402W          | White Optic Lens   | 11-03271 | ---   |
| A402R/W        | Split Red/White Optic Lens                                     | 11-03248 | ---   |
| A406           | Flash Tube Assembly  | 11-03687 | ---   |
| A409           | Clamp Ring Assembly  | 11-03688 | ---   |
| A414A, HDH, CF | HDH,CF Power Supply  | 11-03632 | ---   |
| A417-1         | Interconnecting Cable  | 11-03658 | ---   |
| A421-1         | Warning Decal  | 11-03691 | ---   |
| A425           | Tail Strobe Lens Retainer                                      | 11-03692 | ---   |
| A426           | Wingtip Strobe Lens Retainer                                   | 11-03233 | ---   |
| A427           | Flash Tube Assembly  | 11-03219 | ---   |
| A427-M         | Flash Tube Assembly with Molex Connector                       | 11-03272 | ---   |
| A427-4         | Rubber Pad Spacer  | 11-03693 | ---   |
| A428           | Wingtip Strobe Lens  | 11-03236 | ---   |
| A428-C         | Wingtip Strobe Radio Shielded Lens                             | 11-03694 | ---   |
| A428-D         | Wingtip Strobe Radio Shielded Lens plus A426 Retainer Assembly | 11-03290 | ---   |
| A469A          | Strobe Tube Assembly   | 11-03242 | ---   |
| A430           | Tail Strobe Head Assembly                                      | 11-03696 | ---   |
| A435           | Flash Tube Assembly  | 11-03697 | ---   |
| A440           | WRM-65 Mounting Adapter, for HR,DF & SA,DF                     | 11-03699 | ---   |
| A441           | AMP Connector and 3 Pins                                       | 11-03211 | ---   |
| A442           | AMP Connector and 3 Sockets                                    | 11-03212 | ---   |
| M441           | Molex Connector and 3 Pins for Piper Installation              | 11-04215 | ---   |
| M442           | Molex Connector and 3 Sockets for Piper Installation           | 11-04216 | ---   |
| A444           | AMP Connector and 2 Pins                                       | 11-03700 | ---   |
| M444           | Molex Connector and 2 Pins for Piper Installation              | 11-04217 | ---   |
| A445           | Switch Label   | 11-03701 | ---   |
| A446           | AMP Connector and 2 Sockets                                    | 11-03702 | ---   |
| A450           | Strobe Head Assembly   | 11-03280 | ---   |
| A455           | Gasket   | 11-03703 | ---   |
| A457A          | Tail Light Lens for A500 and A555                              | 11-03227 | ---   |
| A457A-D        | Radio Shielded Tail Light Lens Assembly for A500               | 11-03704 | ---   |
| A466A-1        | Radio Shielded Lens  | 11-03708 | ---   |
| A467           | Gasket for A470  | 11-03709 | ---   |
| A469B          | Flash Tube Assembly  | 11-03225 | ---   |
| A469D-K        | Radio Shielded Kit for A469A                                   | 11-03711 | ---   |

| Model No.     | Description   | Part No. | Price |
|---------------|---|----------|-------|
| A470-D        | Radio Shielded Remote Strobe Head Assembly, Specify Color                                     | 11-03291 | ---   |
| A470-A-D-S    | Strobe Head Assembly, Shielded Red/White  | 11-04976 | ---   |
| A470-D-R-SU   | Radio Shielded Remote Strobe  | 11-03714 | ---   |
| A490 TC CF    | 14V Power Supply  | 11-02661 | ---   |
| A500-V-D-28   | 28V Radio Shielded Tail Position Strobe Light Head Assembly Vertical Mount                    | 11-06407 | ---   |
| A500-V-D-M-14 | Radio Shielded Tail Position & Strobe Light Head Assembly Vertical Mount with Molex Connector | 11-03722 | ---   |
| A500B-V-14    | Tail Position & Strobe Light Head Assembly (Beech)  | 11-03715 | ---   |
| A500B-V-28    | Tail Position & Strobe Light Head Assembly (Beech)  | 11-03716 | ---   |
| A502          | Flash Tube & Socket Assembly  | 11-03723 | ---   |
| A506          | Flash Tube & Socket Assembly  | 11-03274 | ---   |
| A506-B        | Flash Tube & Socket Assembly  | ---      | ---   |
| A506-M        | Flash Tube & Socket Assembly  | 11-03725 | ---   |
| A506-SP       | Flash Tube & Socket Assembly  | 11-03726 | ---   |
| A507          | Lamp Socket Assembly for A555   | 11-03240 | ---   |
| A508-14       | Halogen Lamp for A500, A555, A600   | 11-03216 | ---   |
| A508-28       | Halogen Lamp for A500, A555, A600   | 11-03208 | ---   |
| A509          | Lamp Shield for A500 and A555   | 11-03727 | ---   |
| A510-28       | Lamp Assembly for A500 & A555   | 11-03266 | ---   |
| A50828        | Lamp for A500, A555, & A600   | 11-03208 | ---   |
| A512-V-28     | Tail Position & Strobe Light Head Assembly (Gulfstream Commander)                             | 11-03729 | ---   |
| A540          | Long Mounting Adapter   | 11-03730 | ---   |
| A605          | Base Plate Assembly   | 11-03733 | ---   |
| A606          | Retainer  | 11-03260 | ---   |
| A610          | Flash Tube Assembly   | 11-03213 | ---   |
| A610-M        | Flash Tube Assembly   | 11-03734 | ---   |
| A612          | Magnifying Lens   | 11-03222 | ---   |
| A612-D        | Radio Shielded Lens Retainer Assembly   | 11-03735 | ---   |
| A615          | Lens for A600 Tail Light  | 11-03230 | ---   |
| A616          | Gasket for A600 Tail Light  | 11-03261 | ---   |
| A625          | Tail Strobe Head  | 11-03228 | ---   |
| A625-D        | Radio Shielded Tail Strobe Head Assembly  | 11-03659 | ---   |
| A626          | Retainer Lens   | 11-03229 | ---   |
| A626-D        | Radio Shielded Lens Retainer Assembly   | 11-03736 | ---   |
| A627          | Flash Tube Assembly   | 11-03263 | ---   |
| A628          | Retainer Lens   | 11-03737 | ---   |
| A629          | Gasket  | 11-03660 | ---   |
| A650          | Wingtip Strobe Head Assembly  | 11-03215 | ---   |

